

MIRROR SERIES

DIAMOND PASTE

MIRROR PASTE
WIBBOB LVZLE



AQUA PASTE
AQUA PASTE



MIRROR GEL
WIBBOB CET



MIRROR SERIES

MAXIMIZING POLISHING WORK EFFICIENCY

MIRROR SERIES

There are three types with different properties.

Maximizes capacity depending on application.

シリーズ名称



MP

MIRROR PASTE Oil base diamond paste
Use the supplied diluent liquid to adjust the concentration.



AP

AQUA PASTE Water base diamond paste
Use the supplied diluent liquid to adjust the concentration.
The advantage is the water-based wipe-off ease.



MG


MIRROR GEL
It has already been blended to a standard concentration based on data. No diluent is necessary.

Three dedicated qualities


Excellent cutting ability

Use diamonds with repeated micro fracturing.
The sharpness is sustained
Select the diamond content according to the material, application, and processing method.


Diamond contents



140%



120%



100%



Finish

Made in Japan

Products made in Japan are quality controlled

Capacity

6g and 12g with 20% increased volume.
Three other types are also available: 40g, 65g, and 100g.

Seven types with different diamond content Uniform price regardless of content

MIRROR PASTE, AQUA PASTE, MIRROR GEL

There are three types with different properties.
Maximizes capacity depending on application.

Recommend MAXIMUM 140%	REGULAR 120%	
Recommend RICH 140%	NATURAL 120%	
Recommend GOLD 140%	SILVER 120%	BRONZE 100%

ラベル名称

14 types of color coding


Product number, particle size, and above all, color coding enhance recognition

ITEM														
NO.	1	2	3	4	6	8	10	12	16	20	25	30	40	60
μm	0~1	0~2	1/2~3	2~4	4~6	4~8	5~10	6~12	8~16	10~20	12~25	20~30	30~40	40~60
COLOR	White	Pink	Yellow	Orange	Lime	Mint	Green	Light blue	Blue	Purple	Magenta	Red	Camel	Brown

Five capacities are available

20% increase vol.

Mirror Paste and Aqua Paste are included 5cc diluent liquid.



① 5g + 1g

② 10g + 2g

③ 40g

④ 65g

⑤ 100g



For Mirror Paste
Original
diluted solution



300ml

For Aqua Paste
Original
diluted solution



300ml

Syringe type	Larger type		
① 6 g ② 12 g	③ 40 g	④ 65 g	⑤ 100 g

MP MIRROR PASTE

High efficiency
of work

High-precision
finishing

mirror
paste
maximum
ID



Syringe has
sealed cap



Included
dilution liquid

It is oil base diamond paste.
High diamond specific polishing performance
due to the high lubricity of the oil.

The concentration can be adjusted by using
the included diluent liquid, but it will sustain
elongation and work closely with the workpiece.
Contains no harmful substances to the human body.

Label

Label	MAXIMUM mirror paste maximum	REGULAR mirror paste regular
Diamond content	140% 	120% 

AP AQUA PASTE

Water-soluble Can be rinsed with water.

AQUA
paste
rich
ID



Syringe has
sealed cap



Included
dilution liquid

Use on products that need rinsing with water.
Contains no harmful substances to the human body.

Label

Label	RICH AQUA paste rich	NATURAL AQUA paste natural
Diamond content	140% 	120% 

MG MIRROR GEL

Hassle-free No Uneven No waste



Syringe has sealed cap


This gel stretches well without drying out. Diamond abrasive grains evenly distributed in the gel lead to a beautiful finish.

It has already been blended to a standard concentration based on data. No diluent is necessary.



No waste

Can be used without worrying about mixing, time, or adjusting quantities



Another product



Mirror Gel

Contains no harmful substances to the human body.

Label

	GOLD	SILVER	BRONZE
Label			
Diamond content	140%	120%	100%

How to order

1 Select "Series"

Oil base	Water soluble	No waste
MP MIRROR PASTE	AP AQUA PASTE	MG MIRROR GEL

2 Select "Label"

Series	Label		
MP MIRROR PASTE	140 MAXIMUM	120 REGULAR	
AP AQUA PASTE	140 RICH	120 NATURAL	
MG MIRROR GEL	140 GOLD	120 SILVER	100 BRONZE

3 Select "Color No."

Color	No.	Micron μm	Grit equivalent	Image of the finish
White	No 1	0 ~ 1	#15000	Super mirror finish
Pink	No 2	0 ~ 2	#8000	
Yellow	No 3	1/2 ~ 3	#6000	
Orange	No 4	2 ~ 4	#5000	Mirror finish
Lime	No 6	4 ~ 6	#3000	
Mint	No 8	4 ~ 8	#2500	
Green	No 10	5 ~ 10	#2000	Middle finish
Light blue	No 12	6 ~ 12	#1500	
Blue	No 16	8 ~ 16	#1200	
Purple	No 20	10 ~ 20	#1000	Rough finish
Magenta	No 25	12 ~ 25	#800	
Red	No 30	20 ~ 30	#600	
Camel	No 40	30 ~ 40	#500	
Brown	No 60	40 ~ 60	#400	

4 Select "size"



When in use

Always remove dust from the machined surface before polishing.
Be sure to use a dedicated diluent for Mirror Paste and Aqua Paste.
Syringe-type containers will eject their contents if pushed or pulled strongly with the cap attached before use.
Paste can be wiped off with alcohol or thinner.

Example of order

Mirror Paste Maximum, No12 12g

MP 140 No12 -12g

Series Label Color No. Size

製造元 **ID** インターナショナルダイヤモンド株式会社

東京本社 東京都大田区矢口1丁目8番21号

大阪営業所 大阪市中央区南本町2丁目4番6号インターワンプレイス本町705

名古屋営業所 三重県四日市市安島2丁目11番8号荒木ハイツ308

<http://www.int-dia.co.jp/>

